

Manage Equipment Templates

About Equipment Templates

In VoipNow, the SIP equipments that have Phone terminal extensions assigned to their line(s) and that are owned by administrator(s), service providers, organizations or users can be automatically configured. This feature is called provisioning and it helps setting and maintaining identical configurations for a large number of remote devices.

The VoipNow provisioning system is based on templates. The standard installation comes with a default provisioning template that includes the configuration settings for all supported brands, models, and firmware versions. You can use it to provision the new devices you want to associate to existing organization/user accounts, but if you wish to customize the settings of a device to suit your own requirements, you need to define new templates and modify the [configuration files](#).

To set up, maintain, and manage equipment templates, go to **Unified Communications** in the side menu and click the [Equipment Templates](#) icon under the **System Templates** area.

- [Global Preferences](#)
- [Customize Template Files](#)
- [Import Configuration Files](#)
- [Add Provisioning Templates](#)
- [Operations with Equipment Templates](#)
- [Configuration File Variables](#)