

# How to set up Aastra 480i SIP phone to connect to VoipNow

Applies to VoipNow 3 and higher!

This article explains how to set up a phone terminal (Aastra 480i phones with firmware 1.4.1 and newer) that will be used with the VoipNow phone provisioning module. These recommendations also apply if you happen to do this for the very first time.

## Phone installation

Assuming that your phone is reset to the default configuration::

1. Plug the power cord into the power supply.
2. Plug one end of the ethernet cable into the power supply's J1 port (data and power) and the other end into the phone's switch port.
3. Plug the internet cable into the power supply's J2 port.
4. Connect the handset using the provided cable.

For more information on the physical installation, check the phone terminal's user guide provided by the vendor.

## Configuration of phone network parameters

If the administrator has set up DHCP, the phone will automatically get its network parameters from the DHCP server. At this point, you can skip directly to the [Configuration of phone provisioning parameters](#) section.

If the administrator has not set up DHCP, you must assign a static IP address to the phone. To do this, take the following steps:

1. Press the **Options** key on the phone pad. The **Setup** menu is displayed on the LCD screen. Use the up and down arrow keys to navigate through the menu.
2. Navigate to the **Network** entry. Press the key corresponding to the **Show** option on the screen. The **Network** menu will be displayed on the LCD screen.
3. Enter the default password, 22222 for admin.
4. In the **Network** menu, go to DHCP and press the key corresponding to the **Change** option to select **No** instead of **Yes**. Press **Done** to save the changes.
5. Go to the **IP Address** option and press the key corresponding to the **Show** option on the screen.
6. Using the keypad, enter the IP address provided by your network administrator and press **Done** to save it.
7. Repeat previous steps for each of the following entries: **Subnet Mask**, **Default Gateway** and **DNS** using the appropriate menus.
8. When finished, press the key corresponding to the **Done** option and restart the phone for the changes to take effect.

## Configuration of phone provisioning parameters

1. Open a web browser and type `http://<Phone IP Address>` in the address bar. Assuming that everything was configured correctly, the browser should display the phone web interface.  
You can find the IP address assigned to your phone by pressing the **Options** button. Use the arrow keys to navigate to the **Phone Status** entry. Press the key corresponding to **Show**. Select the **Network Status** menu and then press **Show** again. Next, press the key corresponding to the **IP Address** option on screen to locate the device's IP.
2. You will be asked to provide the username and the password: admin and 22222.
3. Go to the **Configuration Server** menu available in the left side of your screen.
4. Select the **Download Protocol** as chosen in VoipNow.
5. Enter the required data for the HTTP provisioning server. Here's an example of a valid provisioning link: `http://192.168.9.210/pro/p/0002/0003/001`  
The provisioning path is the link where the phone will find the configuration files. This link is usually provided by the administrator. In case you did not receive it, check the [Appendix](#) to learn how to obtain it yourself. The path format is `http://<Server IP address>/<Root sub-directory path>`
  - Enter the **<Server IP address>** in the **HTTP Server** field. In our example you would have to enter: 192.168.9.210.
  - Enter the **<Root sub-directory path>** in the **HTTP Path** field. In our example you would have to enter: `pro/p/0002/0003/001`.
6. Under **Auto-Resync**, set **Mode** to Configuration Files.
7. Set the **Time** option to your current time. Provisioning is done within a random period between **Time** and **Time + 15 minutes**. Also remember that by changing line preferences from the phone's web user interface you prevent provisioning, because these changes are not overwritten by provisioning.
8. Save the changes.
9. From the **Reset** menu available in the left side of your screen, click the **Restart** button.

## Appendix

If your administrator lets you provide the link for the phone yourself, then you should take the following steps:

**STEP 1:** Log in to the VoipNow web interface with your extension account.

**STEP 2:** Click the **Provisioning and SIP** icon available in the **Telephony** section.

**STEP 3:** Customize the following fields taking into consideration the explanations below:



## Provisioning

- **Use provisioning** - When enabled, the phone device associated with the extension will get all its setup parameters from the provisioning server. Otherwise, the extension user will have to set the phone parameters manually.
- **Regenerate provisioning location** - When enabled, VoipNow will delete the current configuration file and will create a new one.

## Device Information

- **Friendly name** - Fill in a custom name that will differentiate the provisioned device
- **Phone brand and model** - From the drop-down list, select your phone terminal brand and model.
- **Firmware** - From the drop-down list, select the firmware version corresponding to your phone terminal.
- **Phone MAC** - Fill in the phone's MAC address. You will find it on the back of the phone device. The MAC address for Cisco phones begins with 0018B9.
- **Use MAC based provisioning** - When enabled, the provisioning link will be generated based on the device MAC address as long as the **Allow MAC based provisioning on HTTP(S)** option is enabled from the **Unified Communications Provisioning templates Global preferences**.

## Device Settings

- **Phone admin username** - You can leave this field empty.
- **Phone admin password** - You can leave this field empty.
- **Confirm phone admin password** - You can leave this field empty.
- **Phone update interval** - The number of minutes the phone waits before checking for updates on the provisioning server.
- **Update protocol** - It's the protocol used by the phone to access the configuration file on the provisioning server.

## SIP Preferences

- **Allowed codecs** - Select the checkboxes corresponding to the codecs supported by the phone device.
- **Equipment description** - You can leave this field empty.

**STEP 4:** Click **OK** to save the data. The provisioning link will be displayed at the top of the screen.

## Related articles

- [How to configure the time for a Phone Terminal through provisioning](#)
- [How to define a new device for provisioning](#)
- [How to configure the time for a Phone Terminal through provisioning](#)
- [How to use the Password Protection feature](#)
- [The provisioning process in VoipNow](#)